


Istruzioni per la pulizia

Cleaning Care



Istruzioni per la pulizia

Quale detergente?

Per la pulizia quotidiana utilizzare un sapone liquido e neutro per le mani.

Per depositi di grasso come crema o spray per capelli una soluzione a base di alcool (poco alcolica)

Come?

Con che frequenza?

- Pulire la superficie quotidianamente o appena si sporca.
- Utilizzare un panno morbido, con un pò d'acqua e sapone neutro.
- Non utilizzare strumenti con effetto abrasivo (p. es. spugne abrasive, panni in microfibra).
- Rimuovere lo sporco più ostinato applicando il detergente su un panno morbido per la pulizia e trattando così il punto interessato.
- Risciacquare con acqua pulita per rimuovere completamente i residui di detergente
- Asciugare la superficie.



AVVISO! Possibile danneggiamento della superficie in caso di pulizia scorretta.



Non utilizzare detergenti contenenti acido cloridrico, acido formico o acido acetico contenenti acido fosforico o candeggina, contenenti parti sulfuree con effetto abrasivo.



Non mescolare mai i detergenti.



Spruzzare il detergente spray su un panno per la pulizia e mai direttamente sul prodotto.



Lo spray nebulizzato può penetrare nelle aperture e nelle fessure provocando dei danni



Adeguate il dosaggio e il tempo di azione del detergente alle specifiche caratteristiche dell'oggetto e non lasciarlo mai agire più del dovuto.

Instructions for cleaning

What kind of cleaner?

For daily cleaning use liquid soap or natural hand soap

If there is cream, hairspray or similar on the surface use alcohol solutions (low alcohol)

How to clean?

How often?

- Daily or when the surface is dirty
- Use a soft cloth with a little water and mild soap
- Do not use abrasive tools (e.g. scouring sponges, microfibre cloths).
- Remove stubborn dirt by applying the detergent to a soft cloth.
- Rinse with clean water to completely remove any detergent residue.
- Dry the surface



CAUTION! Incorrect cleaning may damage the surface.



Do not use detergents containing chloridric acid formic acid, acetic acid, phosphoric acid or bleach, or detergents containing sulphurous components with an abrasive effect.



Never mix detergents.



Spray the cleaner onto a rag, never directly onto the product.



Spraying the detergent directly onto the product could damage the product if it gets into the cracks.



Dose and use the detergent according to the item.



Do not leave the detergent act on the product for longer than necessary.